

- 1.1 Profile with LED strip
- 1.2 Mounting track
- 2.1 Threaded plug
- 2.2 Washer
- 2.3 Nut
- 2.4 Power connector
- 2.5 Locking washer
- 2.6 Nut
- 2.7 Sleeve
- 2.8 Head
- 2.9 Fastener body
- 3. Threaded rod\*
- 4. Ceiling fastener\*
- 5. Power supply (12 V / 24 V)\*
- \*The full range of accessories and electronics is available at www.KlusDesign.eu

Lighting fixture


**NOTE!** All LED tapes must be connected to a 12 V or 24 V power supply.

**IMPORTANT:** Not all possible mounting procedures are presented here. More mounting procedures and related accessories can be found at www.KlusDesign.eu. Drawings of extrusions and accessories in these instructions are simplified and only approximate the actual shapes.

www.KlusDesign.eu 1


PUSZ-PRET-ZD silver (ref. 42282), black (ref. 42282L9005)






www.KlusDesign.eu 2


## **PUSZ-PRET-ZD Fastener – mounting instructions**



www.KlusDesign.eu 3







Suspend the lighting fixture from the ceiling fasteners (4) which are connected to the power supply (12 V / 24 V) (5).

www.KlusDesign.eu 4